

## MAMMOGRAPHY GUIDELINE



---

**SUBJECT: IMPLANT SCREENING**

---

1. Routine full breast CONVENTIONAL CC and MLO views should be obtained, ensuring the compression force only registers minimal degree on the compression indicator.
2. Routine TOMO Displaced Implant CC and MLO views are obtained. A 90-degree lateral can be substituted for a MLO if it shows more tissue.
3. Indicate the implant scars in Epic under the image documentation section on the breast diagram and under previous Breast surgery.