

DR. RINGGER

ACBE

SCOUT: AP abdomen, if large patient do 2 films crosswise

SUPPLIES: Large (empty) double contrast Barium Bag

Balloon inflator (check balloon) and air bulb

POLIBAR Plus Barium jug

Pail in sink with hot water

Place Barium jug in water, keep warm until exam

PROCEDURE: Scout patient and show to Dr.

After placing enema tip, get Dr. for Fluoro

After filling Dr. will stand pt. upright to drain Barium, close valve and Dr. will start filling with air and place pt. supine.

Take Overheads when Dr. leaves the room, continue to add air for overheads.

OVERHEADS: AP (and AP crosswise for flexures if needed)

RPO AND LPO

LPO ANGLED (outlet)

BOTH DECUBES

X-TABLE LATERAL RECTUM (tip removed)

NO POST EVAC