

DR. BANDLER

ACBE

SCOUT FILMS: AP Abdomen (take 2 crosswise if pt. large)

SUPPLIES: Fill empty enema bag with 1000cc warmed Polibar Plus. Attach cufflator and insufflator, (check balloon) run Barium thru tubing.

PROCEDURE: Tip patient and place in **prone position**. Set appropriate Fluoro technique w/ tower over Patient. Tech controls Barium flow and assists patient during exam, takes overhead films and sends with Fluoro Spots to PACS. Write Fluoro time in log.

OVERHEADS: AP or PA flat
AP upright crosswise (for flexures)
RPO and LPO
ANGLED LPO OUTLET
BILAT DECUBES (give 2 puffs air before)
X-TABLE LATERAL RECTUM (Prone-tip out)
No Post Evac unless requested