

**Dr. RINGGER**

**SBFT**

**SUPPLIES:** 2 Containers Ultra R Barium, filled w/ H<sub>2</sub>O  
Compression Paddle

**PROCEDURE:** Show Dr. Scout. Give first Cup of Barium, take AP stomach film. Give second cup, take 15 minute film, AP, then 30 min.

Continue taking films at 30 minute intervals until Ileocecal valve filled.

Show Dr., move Patient into Fluoro Room, have Compression paddle ready.