

## Dr. LEWIS

### Shoulder Arthrogram

#### Scout Images:

Check if recent (6 mos) Outside films available, if not do:  
*Internal* and *external* on CR, send to progress and show  
Fluoro scout - neutral rotation, thumb up (leave on monitor  
REVERSE contrast on fluoro spots before sending to PACS

#### Supplies

1. Myelogram Tray
2. Betadine Solution and Chloraprep both
3. Sodium Bicarb
4. 25g x 1 1/2 needle
5. Size 9 gloves
6. Large bottle Omni 300 (50 cc) \* if MRI t/f use Edson Mix
7. 45 Degree angled wedge sponge
8. Boomerang

#### Procedure

Set appropriate fluoro technique  
Place correct marker on fluoro tower  
Place chucks under patients shoulder w/pt supine  
Place angled wedge sponge under pt.s opposite shoulder  
during Dr.'s fluoro spots

#### Overheads

AP internal (bucky)  
AP external (bucky)  
Axillary (no grid), 75 KV @ 10-12 mAs